

USER MANUAL

TideRider
premium vaporizer

FOR OILS




CONTENTS

- ▶ 1 x TideRider Vaporizer Battery Device
- ▶ 1 x Mini USB Charger
- ▶ 1 x User Manual

FEATURES

- ▶ Easy, variable temperature control
- ▶ Preheating function
- ▶ Button controlled auto or manual operation
- ▶ LED indicator light
- ▶ Overheating protection with automatic switch off
- ▶ Quick, 1 hour charge time; Long battery life
- ▶ Ceramic X-Pro Series coil for a cleaner vape and better flavor

COMPONENTS



* Pods sold separately

OPERATION

BASIC OPERATION

1. Charge device using included USB cable.
2. Insert pod into device with the clear window on the same side as the activation button.
3. Press the activation button 5 times quickly to turn on the device in auto mode.
4. Press and hold activation button and inhale through the mouthpiece to vape.
5. To turn the device off, click the activation button 5 times quickly.

PREHEATING

Preheating is recommended for first use of each pod for priming. To preheat, click the activation button 2 times quickly. The indicator light will flash green while preheating is in progress. Click once to cancel.

TEMPERATURE CONTROL

FIRST USE: Before inserting the pod, click the activation button once to ensure the device is on the lowest setting. [○]

To adjust the temperature, click the activation button 3 times quickly:




CHARGING

A flashing light indicates that the device needs to be recharged. Use the provided mini USB cable and a standard 5 volt wall plug to charge. When charging is complete, the indicator light will automatically switch off.

SPECIFICATIONS

- ▶ **MODEL:** TideRider
- ▶ **DIMENSIONS:** 3.69" x 0.80" x 0.53"
- ▶ **BATTERY CAPACITY:** 420mAh
- ▶ **CHARGING:** Mini USB (included) via Standard 5 volt wall charger (5V +/- 5% 1A-2A)
- ▶ **CHARGING TIME:** 1 Hour
- ▶ **INDICATOR LIGHT AND VOLTAGE GUIDE:**



WARRANTY

1 (one) year limited warranty on electronics with valid proof of purchase. Improper use or storage will void the warranty. To make a warranty claim, contact Coral Reefer Warranty Support at coralreefer.com/warranty or by email at warranty@coralreefer.com.

CLEANING

In most cases, the TideRider will not require maintenance. If needed, we recommend using a dry or slightly moistened cotton swab to clean the charge contacts and the inside of the cradle where the pod is inserted.

CAUTION

- ▶ In case of battery leakage, smell, discoloration, or deformation, discontinue use immediately and contact Coral Reefer Warranty Support.
- ▶ This device contains microchips and sensors. DO NOT DROP.
- ▶ Sale of this product to minors is prohibited.
- ▶ Keep out of reach of children.
- ▶ Keep this device in a dry place. Do not expose to moisture or excessive humidity.
- ▶ Do not leave this device unattended while activated or charging.
- ▶ This device may only be used with compatible pods.
- ▶ Charge this device only with the provided USB cable and a standard 5V, 1A-2A wall plug. Do not use car chargers or battery units to charge this device.
- ▶ To preserve the normal service life of this device, charge the battery fully at least once a month.
- ▶ When not in use, remove the pod and store the pod and device separately.
- ▶ Ensure pod contains oil before use.
- ▶ Do Not Immerse in Water.

TideRider



Coral Reefer® and TideRider™ are registered trademarks. All rights reserved.